## CÓDIGO UTILIZADO:

- Para el medidor de temperatura y humedad:

## Registrador de datos desde la terminal:

```
import sys
import Adafruit_DHT

while True:
   humidity, temperature = Adafruit_DHT.read_retry(11, 23)
```

```
Gráfico en tiempo real:
from matplotlib import pyplot as plt
from matplotlib import animation
import numpy as np
import Adafruit_DHT
sensor = Adafruit DHT.DHT11
pin = 23
fig = plt.figure()
ax = plt.axes(xlim=(0, 30), ylim=(15, 45))
max_points = 30
line, = ax.plot(np.arange(max_points),
         np.ones(max_points, dtype=float) * np.nan, lw=1, c="blue", marker="d", ms=2)
def init():
  return line
h,t = Adafruit_DHT.read_retry(sensor, pin)
def animate(i):
  h, t = Adafruit_DHT.read_retry(sensor,pin)
  v = t
  old_y = line.get_ydata()
  new_y = np.r_[old_y[1:],y]
  line.set_ydata(new_y)
  return line,
anim = animation.FuncAnimation(fig, animate, init_func=init, frames = 200, interval=20,blit =
False)
plt.show()
```

- Para el medidor de NDVI:

## Convertidor de imagen común a imagen con niveles de NDVI:

```
import cv2
import numpy as np
from fastiecm import fastiecm
original = cv2.imread('/home/Luu/3.jpg')
def display(image, image_name):
  image = np.array(image, dtype=float)/float(255)
  shape = image.shape
  height = int(shape[0] / 5) #definen el tamaño
  width = int(shape[1] / 5) #definen el tamaño
  image = cv2.resize(image, (width, height))
  cv2.namedWindow(image name)
  cv2.imshow(image_name, image)
  cv2.waitKey(0)
  cv2.destroyAllWindows()
def contrast stretch(im):
  in_min = np.percentile(im, 5)
  in_max = np.percentile(im, 95)
  out min = 0.0
  out_max = 255.0
  out = im - in_min
  out *= ((out_min - out_max) / (in_min - in_max))
  out += in_min
  return out
def calc_ndvi(image):
  b, g, r = cv2.split(image)
  bottom = (r.astype(float) + b.astype(float))
  bottom[bottom==0] = 0.01
  ndvi = (b.astype(float) - r) / bottom
  return ndvi
display(original, 'Original')
contrasted = contrast_stretch(original)
display(contrasted, 'Contrasted original')
cv2.imwrite('contrasted.png', contrasted)
ndvi = calc ndvi(contrasted)
display(ndvi, 'NDVI')
ndvi contrasted = contrast stretch(ndvi)
display(ndvi contrasted, 'NDVI Contrasted')
cv2.imwrite('ndvi_contrasted.png', ndvi_contrasted)
color mapped prep = ndvi contrasted.astype(np.uint8)
color mapped image = cv2.applyColorMap(color mapped prep, fastiecm)
display(color_mapped_image, 'Color mapped')
cv2.imwrite('color_mapped_image.png', color_mapped_image)
```

## Cámara que mide en tiempo real el nivel de vida de la planta:

```
import cv2
import numpy as np
from fastiecm import fastiecm
class FastieColorMap(object):
  def apply_color_map(self, ndvi_frame):
    normalized ndvi = (ndvi frame + 1) / 2
    color mapped_prep = (normalized_ndvi * 255).astype(np.uint8)
    color_mapped_image = cv2.applyColorMap(color_mapped_prep, fastiecm)
    return color_mapped_image
class SimulatedNDVI(object):
  def convert(self, frame):
    blue = frame[:, :, 0].astype('float')
    red = frame[:, :, 2].astype('float')
    bottom = (blue + red)
    bottom[bottom == 0] = 1 # avoid division by zero
    sim_ndvi = (red - blue) / bottom
    return sim ndvi
def main():
  simulated ndvi = SimulatedNDVI()
  fastie_color_map = FastieColorMap()
  cap = cv2.VideoCapture(0)
  while True:
    ret, frame = cap.read()
    if not ret:
      print("Error: Couldn't capture frame")
    resized_frame = cv2.resize(frame, (720, 600))
    sim ndvi frame = simulated ndvi.convert(resized frame)
    color_mapped_image = fastie_color_map.apply_color_map(sim_ndvi_frame)
    cv2.imshow('Fastie Color Map', color_mapped_image)
    if cv2.waitKey(1) \& 0xFF == ord('q'):
      break
  cap.release()
  cv2.destroyAllWindows()
if __name__ == "__main__":
  main()
```